



*Stopping at Nothing to Get You Stopped*

MATCO mfg  
2361 S 1560 West  
Woods Cross, UT 84087  
801-335-0582  
801-335-0581 (F)  
www.matcomfg.com

## CLAMP METHOD FOR TIRE MOUNTING



1) USE 3 RACHETING BEAM CLAMPS TO COMPRESS TIRE WITH TUBE INSIDE. COMPRESS BEAD SEATS NARROWER THAN MATING WHEEL HALVES.



2) INVERT ASSEMBLY USING THE BEAMS AS 3 LEGGED SUPPORT



3) WHEEL HALF MAY NOW BE ALIGNED WITH VALVE STEM AS NEEDED



4) WHEEL HALVES MAY NOW BE INSTALLED WITH MATING HALVES ABLE TO TOUCH. TUBE CAN BE INSPECTED CLEAR OF HALVES AND NOT PINCHED. INSERT TIE BOLTS AND SECURE EVENLY. CLAMPS MAY THEN BE RELEASED AND BOLT TORQUED AS REQUIRED.